



Datacom Systems Inc

Access Your Network™



VS-1204-10G



VS-1214-10G

VS-1200-10G(-F) Data Access Switches

USERguide

June 2010

VS-1200-10G(-F)-0125-U-A.02

This page intentionally left blank

Product Description

Datacom Systems Inc. VS-1200-10G(-F) Data Access Switches provide an easy method to passively monitor fiber network traffic flowing between devices using your network analysis tools. Using your VS-1200-10G(-F) Data Access Switch, your network analysis tools can be quickly and effectively deployed to the point of failure. Typically the VS-1200-10G(-F) Data Access Switch is installed on a critical fiber link in the network where monitoring and analysis capabilities are important.

VS-1200-10G(-F) Data Access Switch

© 2010 Datacom Systems Inc

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: June 2010 in East Syracuse, New York

Table of Contents

Section 1	Terms of Use	7
1	Copyright.....	7
2	License Agreement.....	7
3	Trademark Attribution.....	7
4	Proprietary Notice.....	7
5	Certifications and Marks.....	8
6	Safety Notices and Warnings.....	9
Section 2	Overview	11
1	What Shipped?	11
2	VS-1200-10G Series Common Specifications.....	12
3	VS-1200-10G Series Specific Specifications	13
Section 3	Hardware	15
1	VS-1200-10G(-F) Series Front Panels.....	15
	Any-to-Any Ports	15
2	10G(-F) Series Rear Panels.....	16
	120-240 VAC Power Modules	16
	40.5-72 VDC Power Modules	16
	Management Module	16
	Rear Label	17
Section 4	Initial Configuration	19
1	Command Line Interface (CLI).....	19
	Basic Functionality	19
	Password Recovery	20
	Basic Commands (Read Only Access)	20
	HELP (HE) or (?)	20
	SHOW (SH).....	21
	SHOW PRODUCT (SH PR)	22
	SHOW TIME (SH TI).....	22
	SHOW SERIAL (SH SE)	22
	SHOW MANAGEMENT (SH MA)	22
	SHOW PORT CONFIG (SH PO CO)	23
	SHOW GROUPS (SH GR)	23
	SHOW PORT ROUTING (SH PO RO)	24
	Superuser Commands (Configuration Access)	24
	SU (SU).....	24
	SET IP (SE IP), SUBNET (SU), GATEWAY (GA)	25
	SET PROMPT (SE PR)	25
	SET DATE (SE DA)	26
	SET TIME (SE TI)	26
	SET PORT NAME (SE PO NA)	26
	SET PORT SPEED (SE PO SP).....	26

1 Terms of Use

The following terms and conditions relate to the use of this document. Please note that Datacom Systems Inc. reserves the right, at its entire discretion, to change, modify, add, or remove portions of these Terms of Use at any time. Please read the Terms of Use carefully as your use of this document is subject to the Terms of Use stipulated herein.

1.1 Copyright

Copyright© 2009 by Datacom Systems, Inc. All rights reserved. Printed in the United States of America. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Datacom Systems, Inc. To obtain this permission, write to the attention of the Datacom Systems legal department at 9 Adler Drive, East Syracuse, New York 13057-1290, or call 315-463-9541.

1.2 License Agreement

Notice To All Users: By using Datacom Systems, Inc. products, you agree to the terms set forth. No licenses, express or implied, are granted with respect to the technology described and Datacom Systems, Inc. retains all rights with respect to the technology described herein. If applicable, you may return the product to the place of purchase for a full refund.

1.3 Trademark Attribution

Access Your Network™, DURAstream™, DS3 ACTIVEtap™, DS3switch™, ETHERNETtap™, Empowering Network Professionals™, FDDIswitch™, FIBERsplitter™, FIBERswitch™, FIBERSWITCHsystem™, FLOWcontrol™, GIGABITswitch™, INSERTswitch™, INSERTunit™, LANswitch™, MANAgents™, MULTINETswitch™, NETspan™, PERMAlink™, PROline™, RMON SWITCHINGanalyzer™, SINGLEstream™, UNIVERSALswitch™, VERSAstream™, and WANswitch™ are trademarks of Datacom Systems, Inc. 1ST in Switching Solutions®, DATACOMsystems®, LANclipper®, MANAgents®, and MULTIVIEW® are registered trademarks of Datacom Systems, Inc. All other registered and unregistered trademarks are the sole property of their respective owners. All specifications may be changed without notice.

1.4 Proprietary Notice

This document contains proprietary information about the VS-1200-10G(-F) family of products and is not to be disclosed or used except as authorized by written contract with Datacom Systems, Inc.

1.5 Certifications and Marks

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



The CE logo indicates that this equipment was tested and found to meet radiated and conducted emission to the European Community EMC Directive 89/336/EEC requirements as per EN 61000-6-3:2001, the generic emissions standard for residential, commercial and light industrial devices, the limits are those for an EN 55022 Class A product.

This equipment also has been tested and found to meet the immunity levels for residential, commercial and light industrial devices according to EN 61000-6-1:2001, the interference severity levels to the standards and requirements of EN 61000-3-2 Harmonic Current, EN 61000-3-3 Voltage Fluctuations and Flicker, EN 61000-4-2 Electrostatic Discharge, EN 61000-4-3 Radiated Susceptibility, EN 61000-4-4 Electrical Fast Transient/Burst, EN 61000-4-5 Surge and EN 61000-4-6 Conducted Susceptibility.

This equipment completed the Product Safety Review and meets the Low Voltage Directive 98/68/EEC requirements to the standards of EN 60950 Safety of Information Technology Equipment.



The RoHS compliant logo indicates that this electronic product does not exceed the limit requirements of toxic, hazardous substances or elements as set forth in Directive 2002/95/EC of the European Parliament and of the Council of 27 January 2003 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.



The crossed out wheelee bin logo signifies that the product can be recycled after being discarded, and should not be casually discarded as set forth in Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment (WEEE).

1.6 Safety Notices and Warnings



These explanatory labels are included in this information for the user in accordance with the requirements of IEC 60825.1.



WARNING: Class 1 laser and LED product. A class 1 laser is safe under all conditions of normal use. Invisible laser radiation may be emitted from optical port openings when no fiber cable is connected, avoid exposure to laser radiation and do not stare into open optical ports.

2 Overview

10G — 10 Gigabit Full Duplex Aggregation — While traditional taps might enable full-duplex monitoring of all traffic on a network link, they transmit the data to the connected monitoring device in two separate half-duplex streams (one for Tx and one for Rx). Not only does this require the monitoring device to have two network interface cards, it also requires that the device be capable of combining and processing both streams of data in order to monitor both sides of the conversation. Not all monitoring systems, including the most popular software solutions, have the required hardware to aggregate traffic.

The *SINGLEstream*TM 10 Gigabit Link Aggregation Tap combines both directions of a 10 Gigabit full duplex data stream and allows any connected monitoring device, including those with only one NIC, to receive a copy of all the data - even in a single trace file.

10G-F — Data Filtering — Instead of tools attempting to keep up with high-speed aggregated traffic streams, the VS-1200-10G-F (with data filtering) provides the option of applying filters to the data to increase tool efficiency and eliminate port over subscription. Line-rate hardware filtering on each port allows you to customize and streamline the amount and type of data each connected monitoring tool receives. Because they are receiving only traffic of interest, tools run faster, data is easier to work with, and issues are resolved quicker. Filters include IP and MAC ranges, VLAN, frame, port number, protocol type, even customizable offsets in the packet header.

Totally Passive and Power Fault Tolerant — Fiber taps are completely passive devices and are not a point of failure on the network. Even if power is lost to the tap, the network traffic will not be affected. If one side of the link fails for any reason, the device on the other side of the link will recognize this outage immediately, so routers and switches can engage redundant protocols and fail-over systems.

Dual Stream Mode — For dual-receive capable tools or times when there is no substitute for full line rate data capture (e.g. network attacks), the *SINGLEstream*TM can be configured to work exactly like a traditional full duplex tap, providing a copy of full-rate Gigabit data to connected tools in two separate streams (Tx and Rx).

Regeneration — One-to-Many configurations replicate copies of identical network traffic to provide multiple tools monitoring access to the same links. In addition to eliminating contention for access to critical links, multiple tools can be connected to the same link for redundancy, testing, or advanced monitoring applications.

Reliable and Easy to Use — Unlike setting up operating systems and binding NICs, the *SINGLEstream*TM Link Aggregation Tap is simple to deploy, and every unit comes with dual redundant power supplies to ensure monitoring uptime.

2.1 What Shipped?

- 1 — VS-1200-10G(-F) series Data Access Switch
- 2 — AC Line Cords
- 1 — DRL512-2M-R serial cable, DB9 M/F straight thru

2.2 VS-1200-10G Series Common Specifications

Management Port (rear): RJ45 @ 100 Mbps Full-Duplex

The factory configured IP Address, Subnet Mask and Default Gateway are as follows:

IP Address: 192.168.1.1

Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

Fiber Tap Split Ratio and Insertion Loss (front): 50/50 — 4dB/4dB
or custom order ratio

Serial Port (rear): 1 - Serial DB9F
1 - Serial DB9M

Input Power Requirement: 100 - 240VAC 50 - 60Hz, 4.0-2.0 A
or
40.5 - 72VDC 10.0 - 5.0 A

Power Consumption: approximately 410.0W

BTU/h: approximately 1,400.0

Operating Temperature: 32° to 104° F — 0° to 40° C

Storage Temperature: -22° to 149° F — -30° to 65° C

Operating Range Relative Humidity: 5 to 90% non-condensing

Dimensions (H x W x D): includes rack mount bracket
1.75 x 19.00 x 21.00 inch
4.44 x 48.26 x 53.34 cm

Weight: 13.5 lbs; shipping: 21.0 lbs — 6.12 kg; shipping; 9.53 kg

Warranty: Two (2) years - see '[Warranty](#)'^[43] section for details.

2.3 VS-1200-10G Series Specific Specifications

VS-1204-10G(-F):

Any-to-Any Ports: 4 - XFP*

VS-1206-10G(-F):

Any-to-Any Ports: 4 - XFP*

Any-to-Any Ports: 2 - SFP**

VS-1214-10G(-F):

Any-to-Any Ports: 4 - XFP*

Any-to-Any Ports: 10 - SFP**

**SFP = Small Form Pluggable can be LX, SX or 1000Mbs copper
(Support Datacom supplied only)

*XFP = 10 Gigabit Small Form Factor Pluggable can be LR, LX, SR or SX
(Support Datacom supplied only)


3 Hardware

Front panel images of the VS-1200-10G(-F) series are provided in this section.


3.1 VS-1200-10G(-F) Series Front Panels

This section provides an illustration and description of the front panel of the VS-1200-10G series.


VS-1204-10G



VS-1206SR-10G



VS-1214-10G



3.1.1 Any-to-Any Ports

Designated as **INPUT** or **OUTPUT** by 'Superuser' for use as input or output ports. See Serial and Management Port - Command Line Interface - Superuser Commands - ['SET PORT MONITOR \(SE PO MO\)'](#)²⁷ section for more information.

PORT 1 through **PORT 4** (VS-1204-10G(-F), VS-1206SR-10G(-F) and VS-1214-10G(-F) series) are XFP (10 Gigabit Small Form Factor Pluggable) optical transceiver used for connection to network devices or tools. The LEDs located to the right of the XFP cage are solid green indicating a light level link has been detected by the respective **PORT** Rx port.

PORT 5 and **PORT 6** (VS-1206SR-10G(-F) series) are dual-duplex LC connectors used for connection to network devices. The LEDs located to the left and right of the LC connectors are solid green indicating a light level link has been detected by the respective **PORT** Rx port.

PORT 5 through **PORT 10** (VS-1214-10G(-F) series) are SFP (1 Gigabit Small Form Factor Pluggable) optical transceiver used for connection to network devices or tools. The LEDs located to the left and right of the SFP cage are solid green indicating a light level link has been detected by the respective **PORT** Rx port.

3.2 10G(-F) Series Rear Panels

This section provides an illustration and description of the rear panel of the 10G(-F) series. The input power is either 120 VAC or 40.5-72 VDC. Not both.



Input Power 120-240 VAC



Input Power 40.5-72 VDC

3.2.1 120-240 VAC Power Modules

Two integral AC power modules are provided for each configurable unit. Although only one power module is required to power the unit, use of a second independent AC power source is strongly recommended to assure uninterrupted monitoring. Furthermore, connecting the second AC input power socket to a different external power source circuit than the first AC input power source eliminates power as a single point of failure.

Input power requirements and other information is provided on this rear label.

3.2.2 40.5-72 VDC Power Modules

Two integral DC power modules are provided for each configurable unit. Although only one power module is required to power the unit, use of a second independent DC power source is strongly recommended to assure uninterrupted monitoring. Furthermore, connecting the second DC input power socket to a different external power source circuit than the first DC input power source eliminates power as a single point of failure.

Input power requirements and other information is provided on this rear label.


3.2.3 Management Module

The **SERIAL 1** port is a shielded DB9 Female connector . and is cabled to the **COM** port of any compatible network tool or PC where HyperTerminal software resides. It is the only port that can easily connect the Management PC to set the IP address (default 192.168.1.1) for the first time.

The **SERIAL 2** port is a shielded DB9 Male connector. When Daisy-chaining 10G series units, the **SERIAL 2** port is cabled to the **SERIAL 1** port of the next 10G unit in the Daisy-chain series.

DB9 nomenclature, Media Access Control (MAC) address identifier, and other information is provided on this rear label.

The **MANAGEMENT PORT** is an RJ45 socket used for 100 Mbps full-duplex connection with a straight-through LAN cable via your management LAN to a Remote Management Console which is a standard PC using any Telnet terminal emulation application.

Management Port LED Display Code				
Code	Left LED		Right LED	Code
Link	Solid Green		Flashing Green	Data

Link indicates connection. The LED Display Code table deciphers the RJ45 jacks with integrated LEDs that display line status of the **MANAGEMENT PORT**.

3.2.4 Rear Label

Attached to the right of the Management Module is a label with Serial Number (SN) identifier, certification compliance identifiers and other information provided.

4 Initial Configuration

IMPORTANT: *Prior to initial configuration of the hardware, it is imperative to review the entire Initial Configuration section before proceeding to the Installation section.*

This section explains the considerations and requirements for the initial configuration of the and VS-1200-10G(-F) series by a Command Line Interface (CLI) with a management PC using a terminal emulation application connected either through the **SERIAL 1** DB9 Female port or through the **MANAGEMENT** RJ45 port. Only one configuration session can be open at a time.

4.1 Command Line Interface (CLI)

The Command Line Interface (CLI) is used to:

- set IP address (default 192.168.1.1), Subnet Mask (default 255.255.255.0) and Default Gateway (default 0.0.0.0)
- set port speed and duplex
- enables the user to select which ports or groups of ports receive the data stream copies
- allows Any-to-Any ports to be configured as either inputs or outputs.

The factory default for all Any-to-Any ports on all Data Access Switches (VS-1200-10G(-F) series) are turned off by default - i.e. they are not set up as either inputs or outputs and are not replicated to any other ports with the exception of the hard-wired in-line taps.

It is strongly recommended that the entire Initial Configuration section be reviewed before proceeding with installation.

4.1.1 Basic Functionality

Window Size Functionality: The CLI window has a limited number of character spaces available (24 lines per screen, 80 characters per line). If more data than can fit is presented, the number of lines is one less and a “—more—” prompt is shown on the last line.

Character Handling: Printable characters (ASCII codes 32-126) and non-printable codes noted below:

Non-Printable Character	Description
• <enter key>	Executes command; places command in history buffer
• <backspace key>	Erases previous character entry; removes history buffer entry

Connectivity/Authentication Functionality: Connectivity to the configurable product is made through the Management RJ45 or Serial DB9 port and authentication is required. This password protection only yields read-only access. To make configuration changes, Superuser (SU) mode must be accessed with another password. See the ['Superuser Commands'](#)^[24] section for more information.

Base Prompt: This is the text presented to the user logging in to use the CLI (default values shown). All Usernames and passwords are case-sensitive.

```
Enter Username: Administrator
Enter Password: admin
>
```

Superuser log in:

```
Example: > SU
        Enter Password: password
        #
```

4.1.2 Password Recovery

Password Recovery is provided for cases where a user has forgotten the Superuser and/or Administrator login password. Password recovery is accomplished by connecting to the unit serially using a HyperTerminal like program and rebooting the unit. As the power-up sequence is occurring, depress <Control> <C>. Upon receipt of this command, a text recovery key will be generated and displayed prior to the prompt. This key is used to reset the passwords. An example recovery key prompt is: 617A6185774\$

You must call Datacom Service Center with this recovery key in order to obtain the required response to reset passwords. Given a valid reset response, the *factory default* passwords will be saved in Non-Volatile memory. If an invalid response is given, a new recovery key will be calculated and displayed at the prompt, as described above, after first clearing the screen.

4.1.3 Basic Commands (Read Only Access)

The following section shows the long form of the basic command set with the shortcut input for the command noted in parenthesis. After the topic heading, a brief overview of the command display function is given followed by an example (Example: >) command input.

All commands, either the exact long form or the shortcut form, are entered after the prompt (default >) at the cursor. No auto-fill mode is available.

4.1.3.1 HELP (HE) or (?)

When this command is entered, a list of commands, their shortcut inputs, and their descriptions will display. For the use and application of each command, refer to the individual command description within this section. A brief display of the HELP data is shown:

Example: > ?

Available commands:

HELP	HE / ?	Show Help
EXIT	EX	Exit Shell
SHOW	SH	Show All Current Configurable Values
SHOW PRODUCT	SH PR	Show Product Name and Serial Number
SHOW TIME	SH TI	Show System Date and Time
SHOW MANAGEMENT	SH MA	Show Management Configuration
SHOW PORT CONFIG	SH PO CO	Show Port Configuration
SHOW GROUPS	SH GR	Show Group Configuration

SET IP	SE IP	Set IP
SET SUBNET	SE SU	Set Subnet Mask
SET GATEWAY	SE GA	Set Default Gateway
SET PROMPT	SE PR	Set Command Prompt (max 32 bytes)
SET DATE	SE DA	Set System Date
SET TIME	SE TI	Set System Time
SET PORT NAME	SE PO NA	Set Port Name (max 32 bytes)
SET PORT SPEED	SE PO SP	Set Port Speed
SET PORT VTAG	SE PO VT	Set Port VTAG Stripping
SET PORT MONITOR	SE PO MO	Set Monitor Configuration
SET PORT VTAP	SE PO VP	Set Virtual Tap
SET PORT GROUP	SE PO GR	Set Group Name
SET MANAGEMENT PORT	SE MA PO	Enable/Disable Management Port
SET TELNET LINUX	SE TE LI	Use the Linux Telnet Client
SET IGNORE PING	SE IG PI	Set to Ignore Pings
SU	SU	Enter Superuser Mode
SU SET PASSWORD	SU SE PA	Set Superuser Password
ACL ADD	AC AD	Allow or Deny Specific IP or IP Ranges Access
ACL DELETE	AC DE	Delete a Specific Record from the Access Control List
SHOW ACL	SH AC	Display Access Control List
ADD USER	AD US	Add User
EDIT USER	ED US	Change Username/Password
DELETE USER	DE US	Delete User
SHOW USERS	SH US	Display Users
SHOW PORT ROUTING	SH PO RO	Display Routing Summary
SET LINK PROTECT	SE LP	Set Link Protect

4.1.3.2 SHOW (SH)

Using this command alone, displays general information about the product as shown:

```
> SHOW (SH)
Date/Time
Product
Serial number
Version
Management port MAC address
Management port IP Address
Management port IP Subnet
Management port IP Default Gateway
```

```
Example: > SH
Date/Time:          02-09-2009 12:05:31
Product:            VS-1204-10G
Serial Number:      9326023
Version:            5.2.0.0
MAC Address:        00-14-E2-0C-0D-0E
```

IP Address:	192.168.1.1
IP Subnet:	255.255.255.0
IP Default Gateway:	0.0.0.0
IP Port:	2370

The following SHOW commands, with other qualifiers, displays more specific information.

4.1.3.3 SHOW PRODUCT (SH PR)

This command displays the name, serial number, and firmware version of the product. It is entered and displays data as shown:

```
> SHOW PRODUCT (SH PR)
  Product Name
  Serial Number
  Firmware Version (x.x.x.x = boot loader. major micro. minor micro. FPGA)
```

```
Example: > SH PR
  Product:      VS-1204-10G
  Serial Number: 9326023
  Version:      5.2.0.0
```

4.1.3.4 SHOW TIME (SH TI)

This command displays the set date and time for the product, it is entered as shown:

```
> SHOW TIME (SH TI)
  DATE and TIME
```

```
Example: > SH TI
  Date/Time 10-09-2007 12:40:25
```

4.1.3.5 SHOW SERIAL (SH SE)

This command displays the serial DB9 port speed for the product, it is entered as shown:

```
> SHOW SERIAL (SH SE)
```

```
Example: > SH SE
  Serial 19200
```

4.1.3.6 SHOW MANAGEMENT (SH MA)

This command displays Management RJ45 port information and authentication information. It is entered and displays data as shown:

```
> SHOW MANAGEMENT (SH MA)
  MAC Address
  IP Address
  IP Subnet
  IP Default Gateway
  IP Port
```

```

Example: > SH MA
MAC Address:          00-14-E2-00-23-9F
IP Address:           192.168.1.50
IP Subnet:            255.255.255.0
IP Default Gateway:  192.168.1.2
IP Port:              2370

```

4.1.3.7 SHOW PORT CONFIG (SH PO CO)

SHOW PORT CONFIG (SH PO CO): This command displays all configurable related data for all ports. It is entered and displays data as shown:

```

> SHOW PORT CONFIG (SH PO CO)
01: Name
    Configuration:          Current:
    Media type:
    Connection type (SPAN, TAP [Ports on TAP circuit]):
    Group membership:
    Steering configuration:
    VLAN tag status:

```

```

Example: > SH PO CO
01: Port 1
    CFG: 1G Full Duplex      Current: No Link
    Type: Tap (1..2:)
    Group Member: TAP
    Copies to: 2,5,6,7,8,9,10
    VLAN Tag Stripping: OFF
02: Port 2
    CFG: 1G Full Duplex      Current: No Link
    Type: Tap (2..1)
    Group Member: TAP
    Copies to: 1,5,6,7,8,9,10
    VLAN Tag Stripping: OFF

```

Press any key...

4.1.3.8 SHOW GROUPS (SH GR)

This command displays all ports as designated by the administrator (Superuser) as belonging to the same logical group. Specifically, groups can be configured as if they were a single logical port, enabling a high degree of control during both the initial setup and all subsequent moves or changes.

The GROUP NAME followed by the ports included in the group are displayed. It is entered and displays data as shown:

```
> SHOW GROUPS (SH GR)
```

GROUP NAME

Port in group (Port number: Port name)

Port in group (Port number: Port name)

Example: > SH GR

TAP:

9: Port 9

10: Port 10

4.1.3.9 SHOW PORT ROUTING (SH PO RO)

SHOW PORT ROUTING (SH PO RO): This command displays, as a quick check, a port routing interface matrix for all ports in a brief summary format. It is entered and displays, in this example, a stand-alone VS-1204-10G(-F) data as shown:

> SHOW PORT ROUTING (SH PO RO)

Example: > SH PO RO

```

                                Outputs
      01  02  03  04  05  06  07  08  09  10
01 -----X---X-----
02 -----X---X-----
03 ---X-----
04 ---X-----
>

```

4.1.4 Superuser Commands (Configuration Access)

The topic headings in the following section show the long form of the Superuser command set with the shortcut input for the command noted in parenthesis. After the topic heading, a brief overview of the command display function is given followed by an example (Example: #) command input.

All commands, either the exact long form of the command or the shortcut form of the command, are entered after the prompt (default #) at the cursor. No auto-fill mode is available.

4.1.4.1 SU (SU)

This command accesses the Superuser mode where the product can be configured. A password prompt is displayed and the default password is "password." Then the Superuser prompt is displayed. It looks exactly like the basic prompt, except the prompt end has turned from ">" to "#," as shown below:

> SU (SU)

Enter Password: *****

#

4.1.4.2 SET IP (SE IP), SUBNET (SU), GATEWAY (GA)

This command configures the IP address (default 192.168.1.1), Subnet Mask (default 255.255.255.0) and Default Gateway (default 0.0.0.0) parameters. Initially, it is highly recommended that this be done through the direct serial connection using the HyperTerminal or equivalent terminal emulation application. Only those variables that require configuration need to be entered.

The parameters may be entered separately as shown:

```
# SET IP (SE IP) [IP Address nnn.nnn.nnn.nnn] [SUBNET] [GATEWAY]
# SET SUBNET (SE SU) [Subnet Mask nnn.nnn.nnn.nnn]
# SET GATEWAY (SE GA) [Default Gateway nnn.nnn.nnn.nnn*n]
```

Example: # SE IP 172.169.50.134

IP will be updated at end of session

```
# SE SU 255.255.0.0
```

Subnet Mask will be updated at end of session

```
# SE GA 172.169.50.1
```

Default Gateway will be updated at end of session

```
#
```

Or, the parameters can also be entered jointly, (i.e., IP Address, Subnet Mask, Default Gateway) but entry must be in the proper sequence order and separated by a space delimiter, as shown:

```
# SET IP [SUBNET] [GATEWAY]
```

Example: # SE IP 172.169.50.134 255.255.0.0 172.169.50.1

IP will be updated at end of session

Subnet Mask will be updated at end of session

Default Gateway will be updated at end of session

```
#
```

4.1.4.3 SET PROMPT (SE PR)

SET PROMPT (SE PR) prompt text: This command, followed by a text string, changes the Base Prompt to the text value entered (up to 32 characters). It is entered as shown:

```
# SET PROMPT (SE PR) prompt text
```

Example: # SE PR Datacom

Datacom#

4.1.4.4 SET DATE (SE DA)

SET DATE (SE DA) MMDDYY: This command, followed by the date (MMDDYY), sets the real time clock date. It is entered as shown:

SET DATE (MMDDYY)

Example: # SE DA 123107
#

4.1.4.5 SET TIME (SE TI)

SET TIME (SE TI) HHMMSS: This command, followed by the time (HHMMSS), sets the real time clock time. It is entered as shown:

SET TIME (HHMMSS)

Example: # SE TI 033526
#

4.1.4.6 SET PORT NAME (SE PO NA)

SET PORT NAME (SE PO NA) port number or port name TO name text: This command, followed by the port number or port name, a command separator (TO), then the name text (up to 32 characters), assigns the new name text entered. It is entered as shown:

SET PORT NAME (SE PO NA) port number or port name TO name text

Example: # SE PO NA 4 TO Port 4
#

4.1.4.7 SET PORT SPEED (SE PO SP)

SET PORT SPEED (SE PO SP): This command changes the port speed for a single port or a group of ports. It is entered as shown:

SET PORT SPEED (Comma separated list of Port numbers, port names, or group names) (Speed duplex) is one of the following: 10HALF, 10FULL, 100HALF, 100FULL, 1000FULL, AUTO.

Example: # SE PO SP 4,6,7,8 100HALF
Speed set for port(s) 4, 6, 7, 8

4.1.4.8 SET PORT VTAG (SE PO VT)

SET PORT VTAG (SE PO VT): This command is used to change the capability of a port to either pass VLAN Tags or strip them from a frame and recalculate the CRC of the frame. It is entered as shown:

SE PO VT (Comma separated list of port numbers, port names, or group names) ON/OFF

Example: # SE PO VT 1,4,6,7 ON
#

4.1.4.9 SET PORT MONITOR (SE PO MO)

SET PORT MONITOR (SE PO MO) port number or port name [OFF] or [FROM comma separated list of port numbers, port names or group names]: This command sets the data routing by selecting the port (output) on which the monitoring device is to be located as well as ports (input TAPS, SPAN) to be redirected to that monitor port. As part of this command, there is a command separator (FROM) or, if the OFF parameter (turn off all data routing to the selected port) is used, the FROM is not used. It is entered as shown:

SET PORT MONITOR (SE PO MO) comma separated list of port numbers, port names or group names [OFF] or [FROM comma separated list of port numbers, port names or group names]

```
Example: # SE PO MO Port1 FROM Engineering
         # SE PO MO 4 FROM 3,2,PortNine
         # SE PO MO 3 OFF
         #
```

NOTE: See the 'Exercise - CLI Setting Ports' and 'Application' sections for further explanation and examples using input and output settings for tap and Any-to-Any ports.

4.1.4.10 SET PORT GROUP (SE PO GR)

SET PORT GROUP (SE PO GR) group name [OFF] or [CONTAINS] port list: This command is used to create a port list under a common name for ease of use. When displayed, the common name is all caps, regardless of case entry. As part of this command, there is a command separator (CONTAINS) or, if the OFF parameter (delete the group) is used, the CONTAINS is not used. A maximum of 10 groups is allowed.

Groups as designated by the administrator (Superuser) belong to the same logical group. Specifically, groups can be configured as if they were a single logical port, enabling a high degree of control during both the initial setup and all subsequent moves or changes. It is entered as shown:

SET PORT GROUP (SE PO GR) group name [OFF] or [CONTAINS] port list

```
Example: # SE PO GR DatacomPorts CONTAINS 4,5,6
         # SE PO GR DatacomPorts OFF
         #
```

4.1.4.11 SET MANAGEMENT PORT (SE MA PO)

SET MANAGEMENT PORT (SE MA PO) [ON/OFF]: This command allows you to enable or disable the management port. This setting is off by default. It is entered as shown:

```
# SET MANAGEMENT PORT (SE MA PO) [ON/OFF]:
```

```
Example: # SE MA PO ON
```

4.1.4.12 SET TELNET LINUX (SE TE LI)

SET TELNET LINUX (SE TE LI) [ON/OFF]: This command allows you to turn the Linux Telnet client on and off. It is turned off by default. It is entered as shown:

```
# SET TELNET LINUX (SE TE LI) [ON/OFF]
```

Example: # SE TE LI ON

4.1.4.13 SET IGNORE PING (SE IG PI)

SET IGNORE PING (SE IG PI) [ON/OFF]: This command allows you to either ignore or respond to ping requests. It is entered as shown:

```
# SET IGNORE PING (SE IG PI) [ON/OFF]
```

Example: # SE IG PI ON

4.1.4.14 SU SET PASSWORD (SU SE PA)

SU SET PASSWORD (SU SE PA): This command is used to change the password used to access Superuser mode. It is entered as shown:

```
SU SET PASSWORD (SU SE PA)
```

Example: # SU SE PA

```
***Warning***
```

```
Modification of the SU password has serious consequences if the password is lost!!
```

```
***Warning***
```

```
# Enter Password: *****
```

```
# Confirm Password: *****
```

```
#
```

4.1.4.15 ACL ADD (AC AD)

ACL ADD (AC AD) ALLOW/DENY ALL/NONE/IP1[TO IP2]: This command allows or denies specific IP or IP ranges from accessing the device. It is entered as shown:

```
# ACL ADD (AC AD) ALLOW/DENY ALL/NONE/IP1[TO IP2]:
```

Example: # AC AD ALLOW 192.168.1.1

4.1.4.16 ACL DEL (AC DE)

ACL DELETE (AC DE) RECNO: This command allows you to delete a specific record from the Access Control List. It is entered as shown:

```
# ACL DELETE (AC DE) RECNO
```

Example: # AC DE 243

4.1.4.17 SHOW ACL (SH AC)

SHOW ACL (SH AC): This command displays the Access Control List. It is entered as shown:

```
# SHOW ACL (SH AC)
```

4.1.4.18 ADD USER (AD US)

ADD USER (AD US): Is used to add users to the configurable product. It is entered as shown:

```
ADD USER (AD US)
```

Example: # AD US

Enter New Username: newuser

Confirm Password: ****

User newuser has been saved

```
#
```

4.1.4.19 EDIT USER (ED US)

EDIT USER (ED US) user name: This command is used to edit Usernames/Passwords of users of the configurable product. It is entered as shown:

```
EDIT USER (ED US) user name
```

Example: # ED US newuser

Enter New Username: edituser

Enter Password: ****

Confirm Password: ****

User edituser has been saved

```
#
```

4.1.4.20 DELETE USER (DE US)

DELETE USER (DE US): This command is used to delete users of the configurable product. It is entered as shown:

```
DELETE USER (USERNAME)
```

Example: # DE US edituser

User edituser deleted

```
#
```

4.1.4.21 SHOW USERS (SH US)

SHOW USERS (SH US): This command displays all users for the configurable product.

```
SHOW USERS (SH US)
```

Example: # SH US

Administrator

edituser

4.1.4.22 SET LINK PROTECT (SE LP)

SET LINK PROTECT (SE LP) tapnum enable interval recovery - This command configures the link protect function for the SS-1200 or SS-2200 integrated tap.

where:

tapnum	specific tap number (1 or 2)
enable	Link Protect ON/OFF
interval	polling interval 1-3600 secs
recovery	AUTO/MANUAL

Factory default is that link protect enable is ON, interval is 10 seconds and recovery is AUTO. If one side of the network traffic, through the SS-1200 or SS-2200 integrated tap, is interrupted ("LINK" dropped) for longer than 10 seconds, the tap will enter bypass mode and the other side of the network will also drop "LINK" with the integrated tap. The TAP will continue to auto recover, as heard when the bypass relays cycle at the polling interval rate, until link is established or the LINK PROTECT settings are changed to different values.

SET LINK PROTECT (SE LP) tapnum enable interval recovery

For example, for a SS-1210BT-BT/SFP, the parameters may be entered as shown:

Example: # SE LP 1 ON 30 AUTO

#

This example command sets the TAP 1 ports (ports 1 and 2) to enable link protect ON, the polling interval is set to 30 seconds and recovery is set to AUTO.

NOTE: Several common conditions could cause the LINK PROTECT function to initiate bypass mode:


- Prior to the installation of the integrated TAP in an active network; with the factory default LINK PROTECT settings; and when LINK is not established within the 10 second polling interval — the LINK PROTECT function will initiate bypass mode.
- If one side of the network link is interrupted for longer than the current polling interval — LINK PROTECT function will initiate bypass mode.

When recovery (AUTO/MANUAL) is set to MANUAL, the TAP will remain in bypass mode once network link is interrupted through the polling interval. LINK is re-established at the Command Line Interface (CLI) by re-executing the SET LINK PROTECT command. The bypass mode can also be reset and LINK re-established by power cycling the TAP.

4.2 SERIAL Port Configuration (DB9)

Note: Use of the **SERIAL1** DB9 Female port, which is fairly simple and straight forward, is strongly recommended for initial configuration of the hardware.

Once VS-1200-10G(-F) series connection is made to the **SERIAL 1** DB9 Female port, open the terminal emulation application and create a connection with settings that fit your needs:



4.2.1 HyperTerminal

The following example utilizes Microsoft HyperTerminal. Any freely available terminal emulator may be utilized, but please take note of the specific HyperTerminal setup settings if an alternate terminal emulator is used.

HyperTerminal (terminal emulator) enter:

115,200 bits per second

8 data bits

Parity none


1 stop bit

Flow control none

After completing review of the [Command Line Interface \(CLI\)](#)^[19] section and Exercise - CLI setting Ports section, detailed IP Address configuration can be found in the [IP Address Configuration](#)^[33] section.

4.3 MANAGEMENT Port Configuration (RJ45)

Once VS-1200-10G(-F) series connection is made to the **MANAGEMENT** RJ45 port, open the terminal emulation application and create a connection with settings that fit your needs:



The factory configured VS-1200-10G(-F) series IP Address, Subnet Mask and Default Gateway are as follows:

IP Address: 192.168.1.1

Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

4.3.1 HyperTerminal

The following example utilizes Microsoft HyperTerminal. Any freely available terminal emulator may be utilized, but please take note of the specific HyperTerminal setup settings if an alternate terminal emulator is used

IMPORTANT: For **Host Address**, if initial IP Address **HAS NOT BEEN** configured, use **192.168.1.1** (default) or if initial IP Address **HAS BEEN** configured, use the **Local Area Network** address input during initial IP Address configuration.

HyperTerminal (terminal emulator) enter:

TCP/IP (Winsock)

Host Address: nnn.nnn.nnn.nnn [i.e., 192.168.1.1 or Local Area Network]

Port Number: 23

Set HyperTerminal (terminal emulator) properties

Under File>Properties>Settings

Emulation: **VT100**

Under File>Properties>Settings>ASCII Setup

Check box: **Send line ends with line feeds**

Check box: **Echo typed characters locally**

After completing review of the [Command Line Interface \(CLI\)](#)^[19] section and Exercise - CLI setting Ports section, detailed IP Address configuration can be found in the [IP Address Configuration](#)^[33] section.

4.3.2 TELNET

Most network equipment and operating systems with a TCP/IP stack also support some kind of TELNET service server for remote configuration. Security-related shortcomings have limited TELNET (TErminaL NETwork) usage, although TELNET is still widely used when diagnosing problems, manually "talking" to other services without specialized client software, and administration of network elements such as integration and maintenance of core network elements.

IMPORTANT: For **hostname**, if initial IP Address **HAS NOT BEEN** configured, use **192.168.1.1** (default) or if initial IP Address **HAS BEEN** configured, use the **Local Area Network** address setting input during initial IP Address configuration.

TELNET using **MANAGEMENT** RJ45 - software configuration of the hardware

At the Windows command prompt enter:

telnet

At the Microsoft Telnet> prompt enter:

o nnn.nnn.nnn.nnn (open hostname) [i.e., o 192.168.1.1 or Local Area Network]

After reviewing the [Command Line Interface \(CLI\)](#)^[19] section and Exercise - CLI setting Ports section, detailed IP Address configuration can be found in the [IP Address Configuration](#)^[33] section.

4.4 IP Address Configuration

All VS-1200-10G(-F) series are shipped with a *factory default* configuration as follows:

IP Address:192.168.1.1

Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

IMPORTANT: If you expect to remotely connect to the VS-1200-10G(-F) series, you must change the IP Address, Subnet Mask and Default Gateway to match your Local Area Network as described in either the [IP Address Configuration with HyperTerminal](#)^[33] section or [IP Address Configuration with TELNET](#)^[35] section.

Note: If your SS-1200-10G(-F) or VS-1200-10G(-F) already has the IP Address, Subnet Mask and Default Gateway set for your network, you may proceed to the [Small Form-Factor Plug Module](#)^[37] section.

4.4.1 IP Address Configuration with HyperTerminal

The IP address of the configurable series can be configured via a serial connection with either Microsoft's **HyperTerminal** application (available on most Windows PCs) or an open source free software terminal emulator for MS-Windows.

Step 1. Plug the VS-1200-10G(-F) into an external power source using a supplied switching AC adapter and AC line cord. Note, POWER 1 or 2 LED is illuminated green indicating power is available from the connected DC power socket.

DC power socket. The other **POWER** LED is not illuminated, indicating a lack of power to the unconnected DC power socket. **POWER 1** or **2**

Step 2. Connect your PC and VS-1200-10G(-F) using the provided Datacom Systems DRL512-2M-R cable. Connect the DB9 Female pin end to the serial port on your PC and connect the DB9 Male pin to the **SERIAL** port on the unit.



NOTE: For PCs without 9-pin serial ports, check with your product representative for available sources of a USB to RS-232 Plug-in Adapter.

Step 3. Open the HyperTerminal application on your PC by selecting **START > All Programs > Accessories > Communications > HyperTerminal**

Step 4. Name a new HyperTerminal connection and select **OK**

Step 5. On the **Connect to** window, create a serial link by selecting the **COM** port assigned to the serial port on your PC from the **Connect using:** pull-down menu and select **OK**

Step 6. Next, configure the **COM Properties**. The initial correct settings to communicate with the SS-1200-10G(-F) or VS-1200-10G(-F) series (115,200, 8, None, 1, None) are shown below. Once all settings are configured correctly, click **Apply**, then click **OK**.

Step 7. You are now connected to your SS-1200-10 or VS-1200-10G(-F) series. Hit the **Enter** key twice in succession (i.e., **Enter, Enter**) to display the **Enter Username:** prompt. All Usernames and passwords are case-sensitive. Type **Administrator** (default value) and press the **Enter** key. At the **Enter Password:** prompt, type **admin** (default value) and press the **Enter** key to display the command line **>** prompt. At the command line **>** prompt, type **su** and press the **Enter** key. At the **Enter Password:** prompt, type **password** (default value) and press the **Enter** key to display the command line **#** prompt. To see a list of available commands, at either the **>** or **#** command line prompt, type **?** and press the **Enter** key.

Step 8. SET IP (SE IP) by typing **se ip xxx.xxx.xxx.xxx** corresponding to a valid IP address for your network. Press the **Enter** key to continue.

Step 9. SET SUBNET (SE SU) by typing **se su xxx.xxx.xxx.xxx** corresponding to your network's subnet mask. Press the **Enter** key to continue.

Step 10. SET GATEWAY (SE GA) (if needed) by typing `se ga xxx.xxx.xxx.xxx` corresponding to your network's default gateway. Press the **Enter** key to continue.

Step 11. SHOW (SH) by typing `sh` and press the **Enter** key to display and affirm that the pending IP Address, IP Subnet and IP Default Gateway match the intended Local Area Network input IP Address, IP Subnet and IP Default Gateway.

Step 12. If the pending IP Address is not correct, repeat **Step 8**, if the pending IP Subnet is not correct, repeat **Step 9** and if the pending IP Default Gateway is not correct, repeat **Step 10**. Repeat **Step 11** to review and verify that the pending IP Address, IP Subnet and IP Default Gateway match the intended Local Area Network input IP Address, IP Subnet and IP Default Gateway.

Step 13. Type `ExampleIT` to save the network address changes and press the **Enter** key to end the connection session indicated by 'Connection closed' response.

Step 14. Close HyperTerminal, respond 'Yes' to the "You are currently connected. Are you sure you want to disconnect now?" prompt and respond 'Yes, No or Cancel,' as you prefer, to the "Do you want to save the connection named "Connect"?" prompt.

Step 15. Disconnect the DRL512-2M-R serial cable.


Step 16. Install the VS-1200-10G(-F) series in your chosen network location.

4.4.2 IP Address Configuration with TELNET

The IP address of the configurable series can be configured via a RJ45 connection with a **TELNET** application (available on most Windows PCs) or an open source free software terminal emulator for MS-Windows.

Step 1. Connect the VS-1200-10G(-F) with one of the supplied switching AC adapters and AC line cords into an external power source. Either **POWER 1** or **2** LED illuminates **green** indicating power is available from the connected source. The other **POWER** LED is not illuminated, indicating a lack of power to the unconnected DC power socket.

Step 2. Using a cross-over Cat 5e cable, connect one end to the VS-1200-10G(-F) **MANAGEMENT** port and the other end to the RJ45 port on your management PC.



Step 3. Check the PC Local Area Network Connection by selecting **START > Control Panel > Network Connections**

Step 4. Right click the Local Area Connection and from the drop down menu select **Properties**. Highlight Internet Protocol (TCP/IP) and highlight and click the **Properties** box. Check the button **Use the following IP Address:** Use IP Address: 192.168.1.5 and Subnet Mask: 255.255.255.0. Click **OK**.

Step 5. Open the Command Prompt on your PC by selecting **START > All Programs > Accessories > Command Prompt**

Step 6. In the **Command Prompt** window, at the prompt, enter TELNET and hit the **Enter** key. (To see a list of available Microsoft Telnet Client Commands, at the prompt, enter ? and hit the **Enter** key. Supported commands will be displayed.)

Step 7. At the **Command Prompt** window prompt, enter o 192.168.1.1 and hit the **Enter** key.

Step 8. You are now connected at the **Enter Username:** prompt. Usernames and passwords are case-sensitive. Type **Administrator** (default value) and press the **Enter** key. At the **Enter Password:** prompt, type **admin** (default value) and press the **Enter** key to display the command line > prompt. At the command line > prompt, type **su** and press the **Enter** key. At the **Enter Password:** prompt, type **password** (default value) and press the **Enter** key to display the command line # prompt. To see a list of available commands, at either the > or # command line prompt, type ? and press the **Enter** key .

Step 9. SET IP (SE IP) by typing **se ip xxx.xxx.xxx.xxx** corresponding to a valid IP address for your network. Press the **Enter** key to continue.

Step 10. SET SUBNET (SE SU) by typing **se su xxx.xxx.xxx.xxx** corresponding to your network's subnet mask. Press the **Enter** key to continue.

Step 11. SET GATEWAY (SE GA) (if needed) by typing **se ga xxx.xxx.xxx.xxx** corresponding to your network's default gateway. Press the **Enter** key to continue.

Step 12. SHOW (SH) by typing **sh** and press the **Enter** key to display and affirm that the pending IP Address, IP Subnet and IP Default Gateway match the intended Local Area Network input IP Address, IP Subnet and IP Default Gateway.

Step 13. If the pending IP Address is not correct, repeat **Step 9**, if the pending IP Subnet is not correct, repeat **Step 10** and if the pending IP Default Gateway is not correct, repeat **Step 11**. Repeat **Step 12** to review and verify that the pending IP Address, IP Subnet and IP Default Gateway match the intended Local Area Network input IP Address, IP Subnet and IP Default Gateway.

Step 14. Type **ExampleIT** and press the **Enter** key to save the network address changes which ends the connection session as indicated in a few seconds by .the Windows informational message balloon pop-up icon "**Local Area Connection - A network cable is unplugged.**"

Step 15. Close TELNET

Step 16. Disconnect the DRL512-2M-R serial cable.

Step 17. Install the VS-1200-10G(-F) series in your chosen network location.

4.5 Small Form-Factor Modules

This section provides information about small form-factor plug SFP and XFP modules.

4.5.1 SFP

This section provides information about small form-factor plug (SFP) modules. The SFP modules are input/output devices that plug into a Gigabit Ethernet (GE) small form-factor (SFF) port, linking the port with a 1000Base-X fiber or 1000Base-T copper network.

The fiber SFP module have a receiver port (Rx) and a transmitter port (Tx) that make up one optical interface. The 1000Base-SX (short wavelength) SFP module operates on standard multimode fiber networks compliant with the 1000Base SX standard. The 1000Base-LX (long wavelength) SFP module operates on standard single-mode fiber networks compliant with the 1000Base LX standard. The fiber SFP module is a 1000 Mbps optical interface in the form of an LC-type duplex port that supports interfaces compliant with the 1000Base-X standard.

The copper SFP module is compliant with the 1000Base-T standard and operates on standard Category 5 wiring and has an RJ45 connector.

4.5.1.1 Installation Prerequisites

This section describes safety and compliance guidelines you should observe before you install an SFP module in your VS-1200-10G(-F) series unit.

NOTE: You can install and remove SFP modules with power on to the system; however, it is strongly recommended that you do not install or remove the SFP module with fiber or copper cables attached to it. Disconnect all cables before removing or installing a SFP module.

CAUTION: Prevent system problems, use only Datacom Systems Inc. supplied SFP modules.

4.5.1.2 Safety Guidelines

Before handling a SFP module, observe the following guidelines:

- Copper and fiber SFP modules are static-sensitive. To prevent electrostatic discharge (ESD) damage, follow your normal ESD handling procedures.
- Fiber SFP modules are dust-sensitive. When storing a SFP module or when a fiber cable is not plugged in, always keep plugs in the SFP module optical hole.
- The most common source of contaminants in the fiber SFP optical aperture is debris picked up on the terminations of the optical connectors. Use an alcohol swab or lint-free absorbent wipes to clean the terminations of the optical connector.

WARNING: Fiber SFP modules are class 1 laser and LED products. Invisible laser radiation may be emitted from the port opening when no fiber cable is connected, avoid exposure to

laser radiation and do not stare in open optical ports.



4.5.1.3 SFP Module Installation

SFP modules might ship already installed in your VS-1200, or they might arrive packaged separately. This section describes how to install the SFP module.

NOTE: You can install SFP modules with power on to the system; however, it is strongly recommended that you do not install the SFP module with fiber or copper cables attached to it. Disconnect all cables before installing a SFP module.

CAUTION: Prevent system problems, use only Datacom Systems Inc. supplied SFP modules.

Step 1. Turn the SFP module so the latch is towards the center of the Gigabit Ethernet Interface sockets. The SFP module is keyed so that it cannot be inserted incorrectly.

Step 2. Insert the SFP module into the SFF port and repeat **Step 1** and **Step 2** inserting other SFP modules until completed.

Step 3. Attach the appropriate network cable to the LC-type or RJ45-type connector on the SFP module. For fiber optic SFP modules you can use either simplex or duplex connectors. For simplex connectors, two cables are required, one cable for transmit (Tx) and a second cable for receive (Rx). For duplex connectors, only one cable that has both Tx and Rx connectors is required.

4.5.1.4 SFP Module Removal

SFP modules might ship already installed in your VS-1200, or they might arrive packaged separately. This section describes how to remove the SFP module.

NOTE: You can remove SFP modules with power on to the system; however, it is strongly recommended that you do not remove the SFP module with fiber or copper cables attached to it. Disconnect all cables before removing a SFP module.

Step 1. Disconnect the network cable from the SFP module LC-type or RJ45-type connector.

Step 2. Release the SFP module from the GE SFF port by moving the swing latch away from the body of the unit.

Step 3. Slide the SFP module out of the GE SFF port.

4.5.2 XFP

This section provides information about small form-factor plug (XFP) modules. The XFP modules are input/output devices that plug into a Gigabit Ethernet (GE) small form-factor (SFF) port, linking the port with a 1000Base-X fiber or 1000Base-T copper network.

The fiber XFP module have a receiver port (Rx) and a transmitter port (Tx) that make up one

optical interface. The 1000Base-SX (short wavelength) XFP module operates on standard multimode fiber networks compliant with the 1000Base SX standard. The 1000Base-LX (long wavelength) XFP module operates on standard single-mode fiber networks compliant with the 1000Base LX standard. The fiber XFP module is a 1000 Mbps optical interface in the form of an LC-type duplex port that supports interfaces compliant with the 1000Base-X standard.

The copper XFP module is compliant with the 1000Base-T standard and operates on standard Category 5 wiring and has an RJ45 connector.

4.5.2.1 Installation Prerequisites

This section describes safety and compliance guidelines you should observe before you install an XFP module in your VS-1200-10G(-F) series unit.

NOTE: You can install and remove XFP modules with power on to the system; however, it is strongly recommended that you do not install or remove the XFP module with fiber or copper cables attached to it. Disconnect all cables before removing or installing a XFP module.

CAUTION: Prevent system problems, use only Datacom Systems Inc. supplied XFP modules.

4.5.2.2 Safety Guidelines

Before handling a XFP module, observe the following guidelines:

- Copper and fiber XFP modules are static-sensitive. To prevent electrostatic discharge (ESD) damage, follow your normal ESD handling procedures.
- Fiber XFP modules are dust-sensitive. When storing a XFP module or when a fiber cable is not plugged in, always keep plugs in the XFP module optical hole.
- The most common source of contaminants in the fiber XFP optical aperture is debris picked up on the terminations of the optical connectors. Use an alcohol swab or lint-free absorbent wipes to clean the terminations of the optical connector.

WARNING: Fiber XFP modules are class 1 laser and LED products. Invisible laser radiation may be emitted from the port opening when no fiber cable is connected, avoid exposure to laser radiation and do not stare in open optical ports.



4.5.2.3 XFP Module Installation

XFP modules might ship already installed in your VS-1200-10G, or they might arrive packaged separately. This section describes how to install the XFP module.

NOTE: You can install XFP modules with power on to the system; however, it is strongly recommended that you do not install the XFP module with fiber or copper cables attached to it. Disconnect all cables before installing a XFP module.

CAUTION: Prevent system problems, use only Datacom Systems Inc. supplied XFP modules.

Step 1. Turn the XFP module so the latch is towards the center of the Gigabit Ethernet Interface sockets. The XFP module is keyed so that it cannot be inserted incorrectly.

Step 2. Insert the XFP module into the SFF port and repeat **Step 1** and **Step 2** inserting other XFP modules until completed.

Step 3. Attach the appropriate network cable to the LC-type connector on the XFP module. For fiber optic XFP modules you can use either simplex or duplex connectors. For simplex connectors, two cables are required, one cable for transmit (Tx) and a second cable for receive (Rx). For duplex connectors, only one cable that has both Tx and Rx connectors is required.

4.5.2.4 XFP Module Removal

XFP modules might ship already installed in your VS-1210-10G, or they might arrive packaged separately. This section describes how to remove the XFP module.

NOTE: You can remove XFP modules with power on to the system; however, it is strongly recommended that you do not remove the XFP module with fiber or copper cables attached to it. Disconnect all cables before removing a XFP module.

Step 1. Disconnect the network cable from the XFP module LC-type connector.

Step 2. Release the XFP module from the GE SFF port by moving the swing latch away from the body of the unit.

Step 3. Slide the XFP module out of the GE SFF port.

5 Hardware Installation

This section describes specifically the VS-1200-10G(-F) hardware installation at the network site of your choice.

5.1 Power

This section describes the power connection at the network installation site of the VS-1200-10G(-F) series unit.

Two input power sockets for AC or terminal blocks for DC are provided on the rear panel. The front panel **POWER 1** and **2** LEDs are illuminated **green**, respectively when the **POWER** switch is depressed **ON** and power is available at both the two rear power input connectors.


Either **POWER 1** or **2** LED not illuminated when powered, indicates a defective power source and immediate investigation as to the cause is required to insure redundant power integrity.

Step 1. Using the supplied Power Adapters and AC Line Cords, plug the VS-1210 series into different circuit external power sources.

Although only one power source is required to power the configurable unit, use of a second independent power source is strongly recommended to assure uninterrupted monitoring. Furthermore, connecting the second power source to a different external power source circuit that the first power source eliminates power as a single point of failure.

5.2 Any-to-Any Connection

This section will focus on the **Any-to-Any** port connection of the VS-1200-10G(-F) hardware installation.



NOTE: For the VS-1200 unit with a 10 Gigabit Ethernet (GE) small form-factor (SFF) port, the XFP or SFP modules might ship already installed in your unit, or they might arrive packaged separately. See the '[Small Form-Factor Modules](#)^[37]' section, on '[XFP Module Installation](#)^[40]' and '[SFP Module Installation](#)^[38].'


Step 1. Connect a network or monitoring cable to an **Any-to-Any** port socket and the other side of

this cable to the network device or monitoring tool NIC port as appropriate..

Step 2. Continue repeating **Step 1.** for any remaining **Any-to-Any** port socket you want connected from the VS-1200-10G(-F) unit.


5.3 Management Connection

This section shows the **MANAGEMENT** port 100 Mbps Full-Duplex connection of the typical VS-1200 configurable series hardware installation.



Step 1. Connect a network cable to the **MANAGEMENT** port RJ45 socket. The **MANAGEMENT** port RJ45 left LED illuminates **green** when link has been established with the network. The **MANAGEMENT** port right LED illuminates **green** when passing data.

The **MANAGEMENT** port is an RJ45 socket used for 100 Mbps full-duplex connection with a straight-through LAN cable via your management LAN to a Remote Management Console which is a standard PC using a Telnet terminal emulator software application.

Management Port LED Display Code				
Code	Left LED		Right LED	Code
Link	Solid Green		Flashing Green	Data

Link indicates connection. The LED Display Code table deciphers the RJ45 jacks with integrated LEDs that display line status of the **MANAGEMENT** port.

6 Customer Service

This *USERguide* was written to help you get to know your new DATA ACCESS SWITCH quickly and easily. We would welcome any comments or suggestions you may have regarding this *USERguide*. Please send your remarks and recommendations via mail, telephone, facsimile, or Internet E-mail.

Datacom Customer Service is available via telephone, facsimile, and Internet E-mail. Please leave a voice message and our Customer Service Staff will return your call as soon as possible. You may also find the assistance you need at our website: <http://www.datacomsystems.com>.

E-mail: support@datacomsystems.com
Tel: (315) 463-9541
FAX: (315) 463-9557
WEB: www.datacomsystems.com

6.1 Internet

You can obtain additional information about Datacom Systems, Inc. and its products and services from the Internet at:

<http://www.datacomsystems.com>.

6.2 Warranty

Datacom Systems, Inc. (DSI) warrants that the hardware which it supplies will be free from significant defects in materials and workmanship for a period of two years from the date of delivery (Warranty Period), under normal use and conditions. In the event of any such defect, you can return an item of defective hardware, freight prepaid, to DSI during the Warranty Period, and DSI will repair or replace the defective equipment and return it to you, freight prepaid. If DSI determines that the equipment is not defective, it will return it to you, freight collect. DSI shall have no responsibility for any deficiency resulting from accidents, misuse, modifications, power disturbances (including use of a power supply not specified by DSI), or various other forms of disaster, e.g., earthquakes, floods, etc.

PLEASE DO NOT ATTEMPT TO RETURN ANY ITEM PRIOR TO RECEIVING A RETURN MATERIAL AUTHORIZATION (RMA) NUMBER FROM DATACOM CUSTOMER SERVICE AT (315) 463-9541 or support@datacomsystems.com

6.3 Limits of Liability

The warranties set forth above are exclusive and in lieu of all other warranties. Datacom Systems, Inc. (DSI) makes no other warranties, expressed or implied, and DSI expressly disclaims all other warranties, including but not limited to implied warranties of merchantability and fitness for a

particular purpose. Moreover, the provisions set forth above state DSI's entire responsibility and your sole and exclusive remedy with respect to any breach of warranty or contract.

No liability for consequential damages. Under no circumstances and under no theory of Liability shall DSI be liable for costs of procurement of substitute products or services, lost profits, lost savings, loss of information or data, or any other special, indirect, consequential or incidental damages, arising in any way out of the sale of, use of, or inability to use, any DSI product or service, even if DSI has been advised of the possibility of such damages.

Datacom Systems Inc.

9 Adler Drive • East Syracuse, NY 13057

TEL: (315) 463-9541 • FAX: (315) 463-9557

<http://www.datacomsystems.com>



Datacom Systems Inc

Access Your Network™